



Ez-Kleen Care and Cleaning Guide

GENERAL CLEANING and MAINTENANCE: To keep your Ez-Kleen faux leather product looking great, it is recommended that a regular cleaning be scheduled to be maintained. Spills and stains should be cleaned up as soon as they appear. Ordinary dirt, smudges, and water-soluble stains such as coffee, tea, juice, soft drinks, milk, beer, and wine can be removed with mild soap and water. Use a clean cloth or soft sponge to wipe the stain with soapy water gently. Don't stop there – it's important to remove any remaining soap solution by wiping the area with a cloth and clean water, and finally to dry the surface with a soft lint-free cloth or towel. Avoid cleaners containing abrasives, as these can damage the product's coating. A 10:1 ratio of water to bleach solution may be used as a disinfectant. Rinse the surface with clean water after disinfecting. Dry with a soft, lint-free cloth or towel.

DIFFICULT STAINS: Although Ez-Kleen performance fabrics are resistant to most common stains, the dyes and pigments in some staining agents can create a permanent stain if not treated properly. To clean difficult stains from Ez-Kleen upholstery use a household cleaner such as Formula 409® All-Purpose Spray Cleaner. After cleaning rinse the area with fresh water then dry with a clean, lint-free cloth. If a ghost stain remains, use a solvent-type cleaner, such as rubbing alcohol (isopropyl alcohol-91%). Rinse the cleaned area with fresh water then dry with a clean, lint-free cloth.

SUNLIGHT: Faux leather, like most upholstery fabric, can fade and break down if left sitting in direct sunlight for extended periods. Unless you're using upholstery that's been specifically designed to withstand harsh rays, protect it by keeping it out of direct sunlight.

APPROVED CHEMICAL CLEANERS: The following chemical cleaners/disinfectants have been approved for use on Mitchell products provided the manufacturers' directions are followed.

Bleach 10:1

Accel PREvention

Accel TB

BirexSE

CaviWipes

Clorox Commercial Solutions Hydrogen Peroxide Cleaner Disinfectant

Clorox Healthcare Bleach Germicidal Wipes

Clorox Healthcare Citrace Hospital Disinfectant

Clorox Healthcare EZKILL Quat Alcohol Cleaner Disinfectant Wipes
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes
Clorox® Disinfecting Wipes
Clorox Healthcare® VersaSure® Cleaner Disinfectant Wipes
Clorox Pro® Clorox Disinfecting Wipes
Clorox Pro® Disinfecting Bio Stain and Odor Remover
Clorox Pro® Total 360® Disinfectant Cleaner
Isopropyl Alcohol, 70%
Lysol® All-Purpose Cleaner
Lysol® Disinfectant Spray
Lysol Disinfecting Wipes (all scents)
Lysol® IC Foaming Disinfectant Cleaner
Neutral Disinfectant Cleaner
Optim® 33TB Wipes
Oxivir® Tb
Oxivir® Tb Wipes
Oxivir® Plus
Perisept
Sani-Cloth AF3
Germicidal Disposable Wipes
Sani-Cloth HB Germicidal Disposable Wipes
Super Sani-Cloth Germicidal Disposable Wipes
Virex® II 256
Virox™ 5

DISCLAIMER: This guide addresses the care and cleaning of the Ez-Kleen collection. The care and cleaning methods covered in the guide will provide the best protection for these products. However, not all stains can be removed, especially if the stains are not addressed immediately. This information does not relieve the user from the responsibility for the correct and safe use of the product and cleaning methods. The Mitchell Group is not responsible for any defect caused by the use of cleaning solutions not included in this guide. Also, the product warranty will be voided if any other cleaning methods are used on this product.

This Care and Cleaning Guide supersedes all previous Guides – 09-17-2025.